

Cabin Air Filter Removal

The information below explains necessary procedures and tools to remove and install the Cabin Air Filter (CAF).

NOTE: This CAF and corresponding installation instructions are designed for multiple vehicles and model years. Although every consideration and resource was used during its creation, the instructions may not match exactly to your vehicle; however it is DENSO's expectation that these instructions will be able to direct the installer through the CAF replacement.

NOTE: This installation instruction is for applications with the cabin air filter located behind the glove compartment.

NOTE: Special tools may be required to complete the cabin air filter removal process.

Glove Compartment Requiring Fastener Removal

1. Remove all fasteners securing the glove compartment.
2. Remove the glove compartment by gently pulling outwards.
3. Disconnect all wire harnesses and any hoses attached to the glove compartment.




Fig. 1

4. Remove any fasteners securing filter housing cover, then pinch or push the tabs on the cover to detach from the filter housing.




Fig. 2

5. Remove the original cabin air filter from the filter housing.

NOTE: Be sure to reuse the cabin air filter tray to maximize the efficiency and lifespan of the filter.




Fig. 3

Glove Compartment without Fastener Removal

1. Open the glove compartment to unhook the damper arm and release stoppers or tabs (*if applicable*).




Fig. 4

2. Lower the glove compartment or gently remove the compartment by pulling outwards (*if applicable*).

3. Remove access panel to expose the filter housing cover (*if applicable*).

NOTE: Some applications may require the removal of a panel-shelf located in front of the access panel. Pull the shelf to remove.

4. Pinch or push the tabs on the housing cover to detach from the filter housing. (See Fig. 2)

5. Remove the original cabin air filter from the filter housing. (See Fig. 3)

NOTE: Be sure to reuse the cabin air filter tray to maximize the efficiency and lifespan of the filter.

Cabin Air Filter Installation

1. Install new cabin air filter element. If filter is equipped with air flow markings, ensure marking is facing the proper direction.
2. Install cabin air filter cover. Ensure cover is properly installed.
3. Reinstall previously removed parts in reverse order.

Noise Test

4. Reconnect the battery ground cable.
5. Engine ON, A/C ON, blower speed on high.
6. Listen for any abnormal air noises from the air filter area.

